


Product Installation Instructions



BR30 LED Light Bulb (LED)

CAUTION: Turn off light and allow to cool prior to removal.

To complete installation you will need:

- BR30 LED Light Bulb (located in your kit)

Instructions

REMOVE OLD LIGHT BULB

1. First you must choose an incandescent light bulb you will remove and replace with your new LED Light Bulb. Look around your business and determine which light is used the most. This is the bulb you should replace.
2. Always use the lowest wattage bulb that still gives you the light you need.
3. Remove the old incandescent light bulb. **WARNING:** Bulb may be hot.
4. Dispose of the old bulb properly. **WARNING:** Light bulbs are made of thin glass and can cut you if they break.

INSTALL NEW LED LIGHT BULB

5. Carefully remove your new LED Light Bulb from the package. Install your new LED Light Bulb and turn it on!